

Description: Coil defender enzymatic sanitiser and cleaner is a cleaner sanitiser for domestic and commercial use. Could be used for simultaneous cleaning and sanitising of any hard non-porous surface, for example, removable air conditioning filters and air conditioning heat exchange coils.

Instructions for use:

Manual clean: Wipe off or remove gross contamination before processing.

In a sink or any other suitable container, which has marks to measure the volume required, dilute **Coil defender enzymatic sanitiser and cleaner** with hot (45-65°C) water at 1:50 ratio (1 part of **Coil defender enzymatic sanitiser and cleaner** with 49 parts of hot water. Mix well.

- Fully immerse / flood reprocessed items.
- Leave for 10 minutes or longer.
- Rinse thoroughly with running water.
- Do not store dilute solutions.
- DO NOT REUSE.
- Not to be used on medical devices or therapeutic goods.
- Do not heat water above 65°C.
- Discard unused solution in accordance with local, state or federal regulations.
- Hard surface disinfectant only.
- Not to be used on skin.
- Do not mix with detergents or chemicals.

HAZARD STATEMENT:

H315: Causes skin irritation
H319: May Cause serious eye irritation



WARNING

WARNING

KEEP OUT OF REACH OF CHILDREN



**COIL DEFENDER ENZYMATIC
SANITISER AND CLEANER**

**COMMERCIAL GRADE
DISINFECTANT**

KILLS COVID 19

ACTIVE SUBSTANCES:

Benzalkonium chloride 0.98% w/w

**5.0
LITRE NET**



**Poison information Centre in
Australia 131126 in New Zealand
0800 764 766**

OH & Safety: Refer to relevant
Safety Data Sheets (SDS).

**Safety Directions: Safety glasses
and P.V.C. gloves must be worn.**
As with any other detergent, avoid
creating and breathing aerosols.
Avoid contact with skin, eyes and
avoid breathing vapours.

First Aid: If poisoning occurs,
contact a doctor or the Poisons
Information Centre.
If swallowed do not induce
vomiting, drink water. If skin contact
occurs, remove contaminated
clothing and wash skin thoroughly
with soap and water.
If contact with eyes open eyelids
and wash with clean water for 15
minutes. Seek medical advice.



Check for latest SDS,
instructions for use at



XX/XX/XX



XXXXXXXX

Coil Defender

Tel 1300 654 349
Unit 34 / 34-36 Ralph St
Alexandria NSW 2015
www.coildefender.com.au